



MJK Performance Installation Instructions

Brake Arm

Warning – parts have been assembled finger tight for shipping purposes only.

*** Installer must ensure all parts are properly tightened at time of installation! ***

Blue Loctite Threadlocker must be used on all fasteners at installation.

- 5/16" fasteners are to be tightened to 15 to 18 ft-lb of torque.
- 3/8" fasteners are to be tightened to 18 to 25ft-lb of torque.
- Re-use the factory nut on the brake arm pivot shaft.
- All pinch bolts must be re-torqued after 8 hours of riding time, and checked regularly or parts will become dangerously loose.

***Parts to be assembled and installed by a licensed motorcycle mechanic.
For technical support please call 1-855-250-7919.***

THANK YOU FOR YOUR SUPPORT!