



## MJK Performance Installation Instructions

### Max Lean Floor Boards

**Warning** – parts have been assembled finger tight for shipping purposes only.

**\* Installer must ensure all parts are properly tightened at time of installation! \***

- Blue Loctite Threadlocker must be used on all fasteners at installation.
- 1/4" fasteners are to be tightened to 8ft-lb of torque.
- Re-use factory floorboard bracket bolts, and discard the 4 factory nuts.

***Parts to be assembled and installed by a licensed motorcycle mechanic.  
For technical support please call 1-855-250-7919.***

**THANK YOU FOR YOUR SUPPORT!**

---

# **MJK**

## **PERFORMANCE**

***#PERFORMANCEBAGGER***

---