

MJK Performance Installation Instructions

Passenger Pegs

Warning – parts have been assembled finger tight for shipping purposes only.

Installer must ensure all parts are properly tightened at time of installation!

- Blue Loctite the 2 safety set screws only
- 3/8" Stainless Steel Fastener to peg mount torque spec is 20-25 ft-lbs of torque

Parts to be assembled and installed by a licensed motorcycle mechanic. For technical support please call 1-855-250-7919.

THANK YOU FOR YOUR SUPPORT!