



## MJK Performance Installation Instructions

### Touring Rear Axle Adjuster Kit

**\* Installer must ensure all parts are properly tightened at time of installation! \***

***Perform the following procedures after stock assembly has been removed:***

1. Remove lower shock bolts and push shocks aside
2. Place adjustable axle plates in position
3. Move shock into place and insert shock bolt to hold axle plate
4. Repeat procedure for other side
5. Install axle – there is no right or left for installation of axle
6. Hand tighten axle nut
7. Adjust axle by tightening or loosening 5/16" half nuts **WARNING -DO NOT TURN STUD.**
8. Adjust belt or chain to specifications.
9. Rotate wheel forward motion and check the alignment of the belt or chain.
10. Tighten axle nut to 110lb torque
11. Re-check belt or chain tension
12. Spacer washers in the kit are for realignment of the shock installed to upper shock mount.
13. Spools are supplied for use with a sport bike lift

***Axle threads are lubricated with NEVER SEIZE. Stainless must be lubricated to prevent thread galling.***

***Parts to be assembled and installed by a licensed motorcycle mechanic.  
For technical support please call 1-855-250-7919.***

**THANK YOU FOR YOUR SUPPORT!**