

MJK Performance Installation Instructions MJK Riser/Gauge with Handle Bar Kits

* Installer must ensure all parts are properly tightened at time of installation! *

Ignition Delete required for installation

Any Techno Research Dealer or Harley-Davidson Dealer can perform a Switchless mode to eliminate the ignition key. Techno Research features a Switchless mode in their Centurion Digital Diagnostic Tool under the BCM Configuration.

Now your bike can perform without the ignition key by using the Ignition RUN/STOP Switch located on the right hand side of the handle bars. Harley-Davidson CVO's have this same feature.

NOTE: Motorcycle must be equipped with a factory Harley-Davidson Security systems it requires the FOB in order to start.

For easier installation use with the NAMS extended wiring harness Part# NHCX-CB14 (purchased separately, not included in riser kit)

TURN OVER - MORE INSTRUCTIONS ON THE BACK!