



MJK Performance Installation Instructions

Universal Adjustable Shifter

Warning – parts have been assembled finger tight for shipping purposes only.

Installer must ensure all parts are properly tightened at time of installation!

- Blue Loctite Threadlocker must be used on all fasteners at installation.
- 1/4" fasteners are to be tightened to 15-18ft-lb of torque.
- 5/16" fasteners are to be tightened to 25ft-lb of torque.
- All pinch bolts connected to spline shifter shaft must be re-torqued after 8 hours of riding time, and checked regularly or parts will become dangerously loose.

***Parts to be assembled and installed by a licensed motorcycle mechanic.
For technical support please call 1-855-250-7919.***

THANK YOU FOR YOUR SUPPORT!