

FSQ-130ED Photo/Visual System chart

- 6. CAA (CCA-250) [TKP86200]
 - 8. Coupling (TW) (FSQ-130ED) [TKP38003]
 - 8C. Coupling (TW) (CCA-250) [TKP86003]
 - 10. Coupling (FSQ-130ED) [TKP38001]
 - 13. 50.8 Sleeve [TKP00113]
 - 14. Coupling (S) [TKP00103]
 - 18S. Reducer QE 0.73x [TKA36580]
 - 18L. 645 Reducer 0.7x [TKA38580]
 - 18M. F3 Reducer 0.6x [TKA38581]
-
- 27. 4-turret eyepiece holder [TKA00404]
 - 32. T-mount DX-S (EOS) [TKA01250]
T-mount DX-S (Nikon) [TKA01254]
 - 33. T-mount DX-WR (EOS) [TKA0.251]
T-mount DX-WR (Nikon) [TKA01255]
 - 34. 35mm SLR/DSLR camera
 - 35. CA-35 (50.8) [TKA31201]
 - 36. TCA-4 [TKA00210]
 - 46. Eyepiece adapter (31.7mm)
 - 47. Eyepiece (31.7mm) [TKP00101]
 - 48. Eyepiece (50.8mm)
 - 49. Diagonal prism (31.7mm) [TKA00547]
 - 60. Extender Q-1.6x (50.8) [TKA36595]
 - 68. Extender ED 1.5x [TKA37595]
 - 70. Eyepiece adapter 50.8 [TKP27110]
 - 71S. 50.8 Extension tube (S) [TKA00105]
 - 71L. 50.8 Extension tube (L) [TKP31112]
 - 74. Diagonal mirror (50.8) [TKA00543]
 - 75. Adapter (DM) [TKA00111]
 - 81S. Aux ring (S) (FSQ-130ED) [TKA38205]
 - 81L. Aux ring (L) (FSQ-130ED) [TKA38206]

